


1/16 - 1/8 - 1/4 DIN VMD CONTROLLERS CONCISE PRODUCT MANUAL (59377-7)

CAUTION: Installation should be only performed by technically competent personnel. It is the responsibility of the installing engineer to ensure that the configuration is safe. Local regulations regarding electrical installation & safety must be observed - e.g. US National Electrical Code (NEC) and/or Canadian Electrical Code. Impairment of protection will occur if the product is used in a manner not specified by the manufacturer. See Section 1 for Supplementary Installation & Safety Information.


1. INSTALLATION

Some installation details vary between the three model sizes covered by this manual (refer to section 10). These differences have been clearly shown.

Installing Option Modules: 1/16 Din Size Instruments



Installing Option Modules: 1/8 & 1/4 Din Size Instruments




To access modules 1, A or B, first detach the PSU and CPU boards from the front by lifting first the upper, and then lower mounting struts. Gently separate the boards.


- Plug the required option modules into the correct connectors, as shown below.
- Locate the module tongues in the corresponding slot on the opposite board.
- Hold the main boards together while relocating back on the mounting struts.
- Replace the instrument by aligning the CPU and PSU boards with their guides in the housing, then slowly push the instrument back into position.

Note: Option modules are automatically detected at power up.

Option Module Connectors: 1/16 Din Size Instruments



Option Module Connectors: 1/8 & 1/4 Din Size Instruments




Panel-Mounting

The mounting panel must be rigid, and may be up to 6.0mm (0.25inch) thick. Cut-out sizes are:

Cut-Out Dim A
1/16 & 1/8 Din = 45mm
1/4 Din = 92mm

Cut-Out Dim B
1/16 Din = 45mm
1/8 & 1/4 Din = 92mm

For *n* multiple instruments mounted side-by-side, cut-out A is 48*n*-4mm (1/16 & 1/8 Din) or 96*n*-4mm (1/4 Din)



CAUTION: For an effective IP66 & NEMA 4X seal against dust and moisture, ensure gasket is well compressed against the panel, with the 4 tongues located in the same ratchet slot.


Rear Terminal Wiring

USE COPPER CONDUCTORS (EXCEPT FOR T/C INPUT). CABLE RATING 80°C MIN
Single Strand wire gauge: Max 1.2mm (18SWG)


The diagrams below show all possible option combinations. The actual connections required depends on the exact model and options fitted.

CAUTION: Check information label on housing for correct operating voltage before connecting supply to Power Input
Fuse: 100 – 240V ac – 1Amp anti-surge
24/48V ac/dc – 315mA anti-surge

1/16 Din Size Instrument Connections



1/8 & 1/4 Din Size Instrument Connections



***Note:** This controller uses 3-Point Stepping Control. This requires two identical outputs (2 Relays, 2 Triacs, 2 SSR Drivers or 1 Dual Relay) for the valve Open & Close functions. See Output Usage 1-5 in Configuration Mode. At first power-up the message `GoTo Conf` is displayed, as described in section 7 of this manual. Access to other menus is denied until Configuration Mode is completed.

Supplementary Installation & Safety Information

- Compliance shall not be impaired when fitted to the final installation.
- Designed to offer a minimum of Basic Insulation only.
- The body responsible for the installation is to ensure that supplementary insulation suitable for Installation Category II is achieved when fully installed.
- To avoid possible hazards, accessible conductive parts of the final installation should be protectively earthed in accordance with EN61010 for Class 1 Equipment.
- Output wiring should be within a Protectively Earthed cabinet.
- Sensor sheaths should be bonded to protective earth or not be accessible.
- Live parts should not be accessible without the use of a tool.
- When fitted to the final installation, an IEC/CSA APPROVED disconnecting device should be used to disconnect both LINE and NEUTRAL conductors simultaneously.
- Do not position the equipment so that it is difficult to operate the disconnecting device.

WARNING: This product can expose you to chemicals including arsenic, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov

2. SELECT MODE - SLCT

Select mode is used to access the configuration and operation menu functions. It can be accessed at any time by holding down `GO` and pressing `DEL`. In select mode, press `UP` or `DOWN` to choose the required mode, press `GO` to enter. An unlock code is required to prevent unauthorised entry to Configuration, & Setup modes. Press `UP` or `DOWN` to enter the unlock code, then press `GO` to proceed.

Mode	Upper Display	Lower Display	Description	Default Unlock Codes
Operator	OPtr	SLCT	Normal operation	None
Set Up	SEtP	SLCT	Tailor settings to the application	10
Configuration	ConF	SLCT	Configure the instrument for use	20
Product Info	inFo	SLCT	Check manufacturing information	None
Auto-Tuning	Autun	SLCT	Invoke Pre-Tune or Self-Tune	0

Note: Instrument returns to Operator mode after 2 mins without activity

3. CONFIGURATION MODE - ConF

First select Configuration mode from Select mode (refer to section 2). Press `GO` to scroll through the parameters, then press `UP` or `DOWN` to set the required value. Press `GO` to accept the change, otherwise parameter will revert to previous value. To exit from Configuration mode, hold down `GO` and press `DEL` to return to Select mode. **Note:** Parameters displayed depends on how instrument has been configured. Refer to user guide (available from your supplier) for further details. Parameters marked ** are repeated in Setup Mode

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value	
Input Range/Type	inPt		See following table for possible codes	UL	
Code	Input Type & Range	Code	Input Type & Range	Code	Input Type & Range
bC	B: 100 - 1824 °C	LC	L: 0.0 - 537.7 °C	P24F	PIRh20% vs 40%: 32 - 3362 °F
bF	B: 211 - 3315 °F	LF	L: 32.0 - 999.9 °F	PtC	PT100: -199 - 800 °C
cC	C: 0 - 2320 °C	NC	N: 0 - 1399 °C	PtF	PT100: -328 - 1472 °F
cF	C: 32 - 4208 °F	NF	N: 32 - 2551 °F	PtL	PT100: -128.8 - 537.7 °C
jC	J: -200 - 1200 °C	RC	R: 0 - 1759 °C	PtH	PT100: -199.9 - 999.9 °F
jF	J: -328 - 2192 °F	RF	R: 32 - 3198 °F	S0	0 - 20 mA DC
Jc	J: -128.8 - 537.7 °C	S0	S: 0 - 1762 °C	S20	0 - 20 mA DC
Jf	J: -199.9 - 999.9 °F	Sf	S: 32 - 3204 °F	S40	4 - 20 mA DC
Kc	K: -240 - 1373 °C	tC	T: -240 - 400 °C	S50	0 - 50 mV DC
Kf	K: -400 - 2503 °F	tF	T: -400 - 752 °F	S10	10 - 50 mV DC
Pc	K: -128.8 - 537.7 °C	tL	T: -128.8 - 400.0 °C	0.5	0 - 5 V DC
Pf	K: -199.9 - 999.9 °F	tF	T: -199.9 - 752.0 °F	1.5	1 - 5 V DC
LC	L: 0 - 762 °C	P24C	PIRh20% vs. 40%: 0 - 1850 °C	0.10	0 - 10 V DC
LF	L: 32 - 1403 °F	2.10	2 - 10 V DC	0.20	2 - 10 V DC

Note: Decimal point shown in table indicates temperature resolution of 0.1°

Parameter	Lower Display	Upper Display	Adjustment range & Description	Default Value
Scale Range Upper Limit	rUL		Scale Range Lower Limit +100 to Range Maximum	Range max (Lin=1000)
Scale Range Lower Limit	rLL		Range Minimum to Scale Range Upper Limit -100	Range min (Linear=0)
Decimal point position	dPoS		0=xxxx, 1=xxx.x, 2=xx.xx, 3=x.xxx (non-temperature ranges only)	1
Primary Output Control Action	Ctrl	rEu	Reverse Acting	rEu
		dir	Direct Acting	
Motor Travel Time	tr		0.05 to 5.00 (5 secs to 5 mins 0 secs) Time Valve takes to move between its physical end stops (full Open to full Closed).	1.00
Alarm 1Type	ALR1	P_H I	Process High Alarm	P_H I
		P_Lo	Process Low Alarm	
		dE	Deviation Alarm	
		bAnd	Band Alarm	
		nonE	No alarm	
High Alarm 1 value**	PHR1		Range Minimum to Range Maximum in display units	Range Max
Low Alarm 1 value**	PLR1			Range Min

Parameter	Lower Display	Upper Display	Adjustment range & Description
Band Alarm 1 value**	bAL1		1 LSD to span from setpoint in display units
Dev. Alarm 1 value**	dAL1		+/- Span from setpoint in display units
Alarm 1 Hysteresis**	AHY1		1 LSD to full span in display units
Alarm 2 Type**	ALAR2		
High Alarm 2 value**	PHR2		Range Max
Low Alarm 2 value**	PLR2		Range Min
Band Alarm 2 value**	bAL2		Options as for alarm 1
Dev. Alarm 2 Value**	dAL2		
Alarm 2 Hysteresis**	AHY2		
Loop Alarm	LAEn		dISA (disabled) or EnAb (enabled)
Alarm Inhibit	Inh1	nonE	No alarms Inhibited
		ALA1	Alarm 1 inhibited
		ALA2	Alarm 2 inhibited
		both	Alarm 1 and alarm 2 inhibited
Output 1 Usage*	USE1	OPN	Valve Open
		CLS	Valve Close
		AL_d	Alarm 1, Direct
		AL_r	Alarm 1, Reverse
		A2_d	Alarm 2, Direct
		A2_r	Alarm 2, Reverse
		LP_d	Loop Alarm, Direct
		LP_r	Loop Alarm, Reverse
		OR_d	Logical Alarm 1 OR 2, Direct
		OR_r	Logical Alarm 1 OR 2, Reverse
		AND_d	Logical Alarm 1 AND 2, Direct
		AND_r	Logical Alarm 1 AND 2, Reverse
Linear Output 1 Range	LYP1	0.5	0 to 5 V DC output
		0.10	0 to 10 V DC output
		0.20	0 to 20 mA DC output
		4.20	4 to 20 mA DC output
Retransmit Output 1 Scale maximum	ro1H		-1999 to 9999 (display value at which output will be maximum)
Retransmit Output 1 Scale minimum	ro1L		-1999 to 9999 (display value at which output will be minimum)
Output 2 Usage*	USE2		As for output 1
Linear Output 2 Range	LYP2		As for output 1
Retransmit Output 2 Scale maximum	ro2H		-1999 to 9999 (display value at which output will be maximum)
Retransmit Output 2 Scale minimum	ro2L		-1999 to 9999 (display value at which output will be minimum)
Output 3 Usage*	USE3		As for output 1
Linear Output 3 Range	LYP3		As for output 1
Retransmit Output 3 Scale maximum	ro3H		-1999 to 9999 (display value at which output will be maximum)
Retransmit Output 3 Scale minimum	ro3L		-1999 to 9999 (display value at which output will be minimum)
Output 4 Usage*	USE4		As for output 1 except Retransmit of PV or SP is not possible.
Output 5 Usage*	USE5		As for output 1 except Retransmit of PV or SP is not possible.
Display Strategy	dISP		1, 2, 3, 4, 5, 6 or 7 (refer to section 8)
Serial Communications Protocol	Prot	7bn	Modbus with no parity
		7bE	Modbus with Even Parity
		7bo	Modbus with Odd Parity
Serial Communications Bit Rate	bAud	1.2	1.2 kbps
		2.4	2.4 kbps
		4.8	4.8 kbps
		19.2	19.2 kbps
Comms Address	Addr		1 to 255
Comms Write	CoEn	r_wJ	Read/Write
		r_0	Read only
Auxiliary Input A Usage	A_PA	rSP	Remote Setpoint (basic)
		P_in	Valve Position Indication (basic)

Parameter	Lower Display	Upper Display	Adjustment range & Description
Auxiliary Input B Usage	R IPB	rSP P in	Remote Setpoint (Full) Valve Position Indication (Full) P in
Digital Input 1 Usage	d IG1	d IS1 d IR5	Setpoint 1 / Setpoint 2 select** Automatic / Manual select
Digital Input 2 Usage	d IG2	d IS1 d IR5	Setpoint 1 / Setpoint 2 select** Automatic / Manual select Remote / Local setpoint select
Remote Auxiliary Input Range	r IRP	0_20	0 to 20 mA DC input
		4_20	4 to 20 mA DC input
		0_10	0 to 10 V DC input
		2_10	2 to 10 V DC input
		0_5	0 to 5 V DC input
		1_5	1 to 5 V DC input
		100	0 to 100mV DC input
		Pot	Potentiometer (2KΩ minimum) <i>Available on full Aux. (Slot B) only</i>
RSP Upper Limit	rSPu	-1999 to 9999. Remote SP for max. input	Range max
RSP Lower Limit	rSPl	-1999 to 9999. Remote SP for min. input	Range min
RSP Offset	rSPo	Constrained within Scale Range Upper & Scale Range Lower limits	0
Lock Code	CLoc	0 to 9999. Unlock Code for Configuration mode	20

Note: **d IG2** has priority over **d IG1** if both are configured for the same usage. If **d IG1** or **d IG2** = **d IS1** the remote setpoint (RSP) input is disabled.

4. SETUP MODE - **SEtP**

Note: Parameters shown depends on Configuration, complete this before Setup. First select Setup mode from Select mode (refer to section 2). The MAN LED will light while in Setup mode. Press **↻** to scroll through the parameters, then press **▲** or **▼** to set the required value. To exit from Setup mode, hold down **↻** and press **▲** to return to Select mode.

Parameter	Lower Display	Upper Display Adjustment Range & Description	Default Value
Input Filter Time Constant	F ILt	0.0 (Off) or 0.5 to 100.0 secs.	2.0
Process Variable Offset	OFF5	±Span of controller	0
Primary Proportional Band	Pb_P	0.5 to 999.9 % of input span	10.0
Automatic Reset (Integral Time)	R-5t	0.0 to 99.59 (1 sec to 99 mins 59 secs)	5.00
Rate (Derivative Time)	rRtE	0.00 to 99.59 (OFF to 99 mins 59 secs)	0.00
Setpoint Upper Limit	SPuL	Current Setpoint to Range max	R/max
Setpoint Lower limit	SPLL	Range min to Current Setpoint	R/min
Minimum Motor On Time	tOn	0.0 secs to (Motor Travel Time / 10) secs. The minimum drive effort to begin moving valve.	0.0
Set Valve Open Position	PcuL	See instructions below to set the valve's fully open and closed positions.	Max. Aux.
Set Valve Closed Position	PcLL		Min. Aux.
Valve Open Limit	P uL	P ILL +1 to 100 . The maximum position valve will be driven to	100
Valve Closed Limit	P iLL	0 to P uL -1. The minimum position valve will be driven to	0
High Alarm 1 value	PhR1	Range Minimum to Range Maximum	R/max
Low Alarm 1 value	PLR1		R/min
Deviation Alarm 1 Value	dAL1	±Span from SP in display units	5
Band Alarm 1 value	bAL1	1 LSD to span from setpoint	5
Alarm 1 Hysteresis	AHY1	1 LSD to full span in display units	1
High Alarm 2 value	PhR2	Range Minimum to Range Maximum	R/max
Low Alarm 2 value	PLR2		R/min
Deviation Alarm 2 Value	dAL2	±Span from SP in display units	5
Band Alarm 2 value	bAL2	1 LSD to span from setpoint	5
Alarm 2 Hysteresis	AHY2	1 LSD to full span in display units	1
Auto Pre-tune	APt	d ISR (disabled) or EnAb (enabled)	d ISR
Auto/manual Control selection	PoEn		
Setpoint Select shown in Operator Mode	SSEn		
Setpoint ramp adjustment shown in Operator Mode	SPr		
SP Ramp Rate Value	rP	1 to 9999 units/hour or Off (blank)	Off
Setpoint Value	SP	Scale range upper to lower limits. (when dual or remote setpoint options are used, SP is replaced by SP1 & SP2 or LSP - or LSP before the legend indicates the currently active SP)	Scale Range Minimum
Local Setpoint Value	LSP		
Setpoint 1 Value	SP1		
Setpoint 2 Value	SP2		
Setup Lock Code	SLoc		

Setting the Valve Opened & Valve Closed Positions

With **PcuL** in the lower display press **MAN**. The top display shows **oPnG**. Press **▲** to drive open the valve until it reaches the "fully open" end stop. Press **MAN**. The top display will go **Blank** and the Auxiliary Input value will be measured and stored as the value equal to the fully open valve position. Press **↻**. The lower display shows **PcLL**. Press **MAN**. The top display shows **clSG**. Press **▼** to drive closed the valve until it reaches the "fully closed" end stop. Press **MAN**. The top display will go **Blank** and the Auxiliary Input value will be measured and stored as the value equal to the fully closed valve position.

5. AUTOMATIC TUNING MODE - **Atun**

First select Automatic tuning mode from Select mode (refer to section 2). Press **↻** to scroll through the modes, then press **▲** or **▼** to set the required value. To exit this mode, hold down **↻** and press **▲**, to return to Select mode. Pre-tune is a single-shot routine and is thus self-disengaging when complete. If **APt** in Setup mode = **EnAb**, Pre-tune will attempt to run at every power up*. Refer to the full user guide (available from your supplier) for details on controller tuning.

Parameter	Lower Display	Upper Display	Default Value
Pre-Tune	Ptun	On or OFF . *Pre-tune will not engage if setpoint is ramping, or the PV is less than 5% of input span from the setpoint. Indication remains OFF	OFF
Self-Tune	Stun		
Tune Lock	tLoc	0 to 9999	0

6. PRODUCT INFORMATION MODE - **inFo**

First select Product information mode from Select mode (refer to section 2). Press **↻** to view each parameter. To exit from Product Information mode, hold down **↻** and press **▲** to return to Select mode. Note: These parameters are all read only.

Parameter	Lower Display	Upper Display	Description
Input type	In_1	Un_1	Universal input
Option 1 module type fitted	OPn1	nonE	No option fitted
		rLY	Relay output
		SSr	SSR drive output
		tr_1	Triac output
Option 2 module type fitted	OPn2	L in	Linear DC voltage / current output
		nonE	No option fitted
		drLY	Dual Relay output
		rLY	Relay output
		SSr	SSR drive output
		tr_1	Triac output
Option 3 module type fitted	OPn3	L in	Linear DC voltage / current output
		dc24	Transmitter power supply
			As Option 2
Auxiliary Option A module type fitted	OPnA	nonE	No option fitted
		r485	RS485 communications
		d IG1	Digital Input*
Auxiliary Option B module type fitted	OPnb	nonE	No option fitted
		rSP1	Auxiliary Input (full) and Digital Input 2*
Firmware type	FLW		Value displayed is firmware type number
Firmware issue	ISS		Value displayed is firmware issue number
Product Revision Level	PrL		Value displayed is Product Revision level
Date of manufacture	dD^7		Manufacturing date code (mmyy)
Serial number 1	Sn1		First four digits of serial number
Serial number 2	Sn2		Middle four digits of serial number
Serial number 3	Sn3		Last four digits of serial number

7. MESSAGES & ERROR INDICATIONS

These messages indicate that an error has occurred, or there is a problem with the process variable input connection or signal. **Caution: Do not continue with the process until the issue is resolved.**

Parameter	Upper Display	Lower Display	Description
Instrument parameters are in default conditions	GoGo	ConF	Configuration & Setup required. This screen is seen at first turn on, or if hardware configuration has been changed. Press ↻ to enter the Configuration Mode, next press ▲ or ▼ to enter the unlock code number, then press ↻ to proceed
Input Over Range	[HH]	Normal	Process variable input > 5% over-range
Input Under Range	[LL]	Normal	Process variable input > 5% under-range
Input Sensor Break	OPEN	Normal	Break detected in process variable input sensor or wiring.

Aux. Over Range	Normal	[HH]**	Auxiliary input over-range	** also seen wherever Aux value would be displayed
Aux. Under Range	Normal	[LL]**	Auxiliary input under-range	
Auxiliary Input Break	Normal	OPEN**	Break detected in Auxiliary input signal	
Option 1 Error	Err	OPn1	Option 1 module fault	
Option 2 Error		OPn2	Option 2 module fault	
Option 3 Error		OPn3	Option 3 module fault	
Option A Error		OPnA	Option A fault or Aux fitted in both A & B	
Option B Error		OPnb	Option B module fault	

8. OPERATOR MODE - **OPtr**

This mode is entered at power on, or accessed from Select mode (see section 2). Note: All Configuration mode and Setup mode parameters must be set as required before starting normal operations. Press **↻** to scroll through the parameters, then press **▲** or **▼** to set the required value. Note: All Operator Mode parameters in Display strategy 6 are read only (see **d ISP** in configuration mode), they can only be adjusted via Setup mode.

Upper Display	Lower Display	Display Strategy and When Visible	Description
PV Value	Active SP Value	1 & 2 (initial screen)	PV and target value of selected SP Local Setpoints are adjustable in Strategy 2
PV Value	Actual SP Value	3 & 6 (initial screen)	PV and actual value of selected SP (e.g. ramping SP value). Read only
PV Value	(Blank)	4 (initial screen)	Process variable only Read only
Active SP Value	(Blank)	5 (initial screen)	Target value of selected setpoint only. Read only
PV Value	Auxiliary Input Value	7 (initial screen)	PV and Valve Position or Flow Read only
SP Value	SP	1 & 3 - 7 if digital input is not d IS1 and RSP not configured	Target value of SP Adjustable except in Strategy 6
SP1 Value	SP1	Digital input = d IS1 . - lit if active SP = SP1	Target value of SP1 Adjustable except in Strategy 6
SP2 Value	SP2	Digital input = d IS1 . - lit if active SP = SP2	Target value of SP2 Adjustable except in Strategy 6
Local SP Value	LSP	RSP fitted. - or LSP lit if the active SP = LSP	Target value of local setpoint Adjustable except in Strategy 6
Remote SP Value	rSP	RSP fitted. - or rSP lit if the active SP = rSP	Target value of remote setpoint Read only
d IG1 , LSP or rSP	SPS	RSP is fitted, digital input is not d IS1 and SSEn is enabled in Setup mode	Selects local/remote active setpoint LSP = local SP, rSP = remote SP d IG1 = selection via digital input (if configured). Note: selecting LSP or rSP will override digital input, active SP indication changes to LSP Adjustable except in Strategy 6
Actual SP Value	SPrP	rP is not blank	Actual (ramping) value of selected SP. Read only
Ramp Rate	rP	SPr enabled in Setup mode	SP ramping rate, in units per hour Adjustable except in Strategy 6
Active Alarm Status	ALSt	When one or more alarms are active. ALM indicator will also flash	Alarm 2 active Alarm 1 active Loop Alarm active

Manual Valve Control

If **PoEn** is set to **EnAb** in Setup mode, manual control can be selected/de-selected by pressing the **MAN** key in Operator mode, via serial communications, or by changing the status of a digital input if **d IG1** or **d IG2** has been configured for **d IR5** in Configuration mode. While in Manual Control mode, the **MAN** indicator will flash and the lower display will show **oPnG**. If Valve Position Indication is configured, the lower display will show **Pxxx** instead of **oPnG**, where xxx is the valve position as read by the Auxiliary Input. **PO** means the valve is fully closed, **P100** means the valve is fully opened.

Press **▲** to move the valve motor in the "open" direction or **▼** to move the valve motor in the "close" direction. Keep pressing the key until the desired valve position is achieved

9. SERIAL COMMUNICATIONS

Refer to the full user guide (available from your supplier) for details. You cannot connect both configuration port & RS485 port at the same time.

10. SPECIFICATIONS

UNIVERSAL INPUT

Thermocouple: ±0.1% of full range, ±1LSD (±1°C for Thermocouple CJC).
Calibration: BS4937, NBS125 & IEC584.
PT100 Calibration: ±0.1% of full range, ±1LSD.
BS1904 & DIN43760 (0.00385Ω/Ω°C).
DC Calibration: ±0.1% of full range, ±1LSD.
Sampling Rate: 4 per second.
Impedance: >10MΩ resistive, except DC mA (5Ω) and V (47kΩ).
Sensor Break Detection: Thermocouple, RTD, 4 to 20 mA, 2 to 10V and 1 to 5V ranges only. "Close Valve" outputs turn ON.
Isolation: Isolated from all outputs (except SSR driver).
Universal input must not be connected to operator accessible circuits if relay outputs are connected to a hazardous voltage source. Supplementary insulation or input grounding would then be required.

AUXILIARY INPUT

Calibration: ±0.25% of input range ±1 LSD.
Sampling Rate: 4 per second.
Sensor Break Detection: 4 to 20 mA, 2 to 10V and 1 to 5V ranges only. Valve control outputs turn off if RSP is the active SP.
Isolation: Slot A - Basic isolation, Slot B - Reinforced safety isolation from other inputs and outputs.

DIGITAL INPUTS

Volt-free(or TTL): Open(2 to 24VDC) = SP1, Local SP or Auto Mode, Closed(<0.8VDC) = SP2, Remote SP or Manual Mode.
Isolation: Reinforced safety isolation from inputs and other outputs.

OUTPUTS

Relay
Contact Type & Rating: Single pole double throw (SPDT); 2A resistive. 120VAC max. (240V for alarm or indirect switching of valves).
Lifetime: >500,000 operations at rated voltage/current.
Isolation: Basic Isolation from universal input and SSR outputs.

Dual Relay

Contact Type & Rating: 2 x single pole single throw, with shared common; 2A resistive. 120VAC max. (240V for alarm or indirect switching of valves).
Lifetime: >200,000 operations at rated voltage/current.
Isolation: Reinforced safety isolation from inputs and other outputs.

SSR Driver

Drive Capability: SSR drive voltage >10V into 500Ω min.
Isolation: Not isolated from universal input or other SSR driver outputs.

Triac

Operating Voltage: 20 to 140Vrms (280V max. for alarm or indirect switching of valves) @ 47 to 63Hz.
Current Rating: 0.01 to 1A (full cycle rms on-state @ 25°C); derates linearly above 40°C to 0.5A @ 80°C.
Isolation: Reinforced safety isolation from inputs and other outputs.

DC Linear

Resolution: 8 bits in 250mS (10 bits in 1s typical, >10 bits in >1s typical).
Isolation: Reinforced safety isolation from inputs and other outputs.

Transmitter PSU

Power Rating: 19 to 28V DC (24V nominal) into 910Ω minimum resistance.
Isolation: Reinforced safety isolation from inputs and other outputs.

SERIAL COMMUNICATIONS

Physical: RS485, at 1200, 2400, 4800, 9600 or 19200 bps.
Protocol: Modbus RTU.
Isolation: Reinforced safety isolation from all inputs and outputs.

OPERATING CONDITIONS (FOR INDOOR USE)

Ambient Temperature: 0°C to 55°C (Operating), -20°C to 80°C (Storage).
Relative Humidity: 20% to 95% non-condensing.
Altitude: <2000m
Supply Voltage and Power: 100 to 240VAC ±10%, 50/60Hz, 7.5VA (for mains powered versions), or 20 to 48VAC 50/60Hz 7.5VA or 22 to 65VDC 5W (for low voltage versions).

ENVIRONMENTAL

Standards: CE, UL, cUL & CSA.
EMI: Complies with EN61326-1:2013
Safety Considerations: Complies with UL61010-1 Edition 3, EN61010-1 Version 2010 & CSA 22.2 No 1010.192. Pollution Degree 2, Installation Category II.
Front Panel Sealing: To IP66 & NEMA 4X when correctly mounted – see section 1

PHYSICAL

Front Bezel Size: 1/16 Din = 48 x 48mm, 1/8 Din = 96 x 48mm, 1/4 Din = 96 x 96mm.
Depth Behind Panel: 1/16 Din = 110mm, 1/8 & 1/4 Din = 100mm.
Weight: 0.21kg maximum.